

PORTAVALIGIE LATERALE SPECIFICO - SPECIFIC TUBULAR SIDE-CASE HOLDER  
 PORTE-VALISES LATÉRAUX SPÉCIFIQUE - SPEZIFISCHES STAHLROHR-SEITENTRAEGER  
 PORTA MALETAS LATERALES ESPECÍFICO

**BMW F650GS 2000-2007**

**BMW G650GS 2011**

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS  
 INSTRUCCIONES DE MONTAJE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE

**ATTENZIONE - WARNING - ATTENTION**

IL SUPPORTO "A" VA INSERITO TRA IL FIANCHETTO ED IL SILENZIATORE.

THE UPPER SUPPORT "A" MUST BE INSERTED BETWEEN SIDE PANEL AND THE SILENCER

LE SUPPORT "A" DOIT ETRE INSERE' ENTRE LE COTE PLASTIQUE ET LE POT.

①



**SUPPORTO**  
 SUPPORT  
 SUPPORT  
 HALTERUNG  
 SOPORTE

**Q.TY n.2(Dx-Sx)**

②



**PONTE POSTERIORE**  
 REAR BRIDGE  
 PONT POSTÉRIEURE  
 VERBINDUNGSGRÖHR  
 PUENTE TRASERO

**Q.TY n.1**

③



**VITE TBEI M8x20mm**  
 SCREW  
 VIS  
 SCHRAUBE  
 TORNILLO

**Q.TY n.2**

④



**VITE TBEI M6x16mm**  
 SCREW  
 VIS  
 SCHRAUBE  
 TORNILLO

**Q.TY n.2**

⑤



**VITE TBEI M8x25mm**  
 SCREW  
 VIS  
 SCHRAUBE  
 TORNILLO

**Q.TY n.2**

⑥



**VITE TEF M8x25mm**  
 SCREW  
 VIS  
 SCHRAUBE  
 TORNILLO

**Q.TY n.2**

⑦



**RONDELLA Ø6mm**  
 WASHER Ø6mm  
 RONDELLE Ø6mm  
 SCHEIBE Ø6mm  
 ARANDELA Ø6mm

**Q.TY n.2**

⑧



**RONDELLA Ø8mm**  
 WASHER Ø8mm  
 RONDELLE Ø8mm  
 SCHEIBE Ø8mm  
 ARANDELA Ø8mm

**Q.TY n.2**

⑨



**DISTANZIALE Ø14x3mm**  
 Foro Ø8,5mm, V379  
 SPACER  
 ENTRETÔISE  
 DISTANZSTUECK  
 DISTANCIADOR

**Q.TY n.2**

⑩



**FISHER Ø30X25**  
 RIB. 23,7x21 Ø17.4  
 V665  
 EXPANDING TUBE INSERT  
 CHEVILLE  
 ELASTISCHER ROHREINSATZ  
 TACO

**Q.TY n.2**

⑪



**CONO FILETTATO**  
 Ø20.4 a 18.8 M8  
 V667  
 THREADED CONE  
 CONE FILETÉ  
 KEGEL GEWINDE  
 CONO ROSCADO

**Q.TY n.2**

⑫

**COMPONENTI ORIGINALI**  
 ORIGINAL PARTS  
 PARTIES ORIGINALES  
 ORIGINAL BAUTEILE  
 COMPONENTES ORIGINALES

**Q.TY n.-**

