

PIASTRA SPECIFICA - SPECIFIC PLATE  
 PLATINE SPECIFIQUE - SPEZIFISCHE PLATTE - PLETINA ESPECÍFICA


# HONDA XL1000V '99/'02 VARADERO

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS  
 INSTRUCTIONS DE MONTAGE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE



PIASTRA  
 PLATE  
 PLAQUE

Q.TY n.1



VITE TCEI M 8 X 25  
 SCREW M 8 X 25  
 VIS M 8 X 25

Q.TY n.4



TAPPO COPRIFORO  
 COVER HOLE CAP  
 BOUCHON COUVRE  
 TROUE

Q.TY n.6



RONDELLA Ø 8 X 14  
 WASHER Ø 8 X 14  
 RONDELLE Ø 8 X 14

Q.TY n.4



DADO M 8  
 AUTOBLOCCANTE  
 ECROU M 8  
 NUT M 8

Q.TY n.4

**A**

**ATTENZIONE:**  
 TOGLIERE I TAPPI ORIGINALI  
 SOPRA IL PORTAPACCHI.

**WARNING:**  
 TAKE OFF THE ORIGINAL CAPS  
 ON THE LUGGAGE CARRIER

**ATTENTION:**  
 ENLEVER LE BOUCHONS ORIGINALS SUR  
 LE PORTE-PAQUETS D'ORIGINE.

**B**

